



NR-10 1/10 Scale Brushed/Brushless Buggy



Length : 420mm Track Width : 260mm Height : 135mm Wheelbase : 275mm Radio System : 2.4GHz Power : 3650 Brushless Motor Battery : 7.4V Lipo/7.2V Nimh	BH2001 Chassis x1	BH2002 Pivot Block x1	BH2003 Front Lower Arms x2	BH2006 Rear Lower Arms x1	BH2008 Drive Shaft x1	BH2009 Joint Cup x2	BH2010 Pinion Gear 19T x1	BH2011 Slipper x1	BH2012 Gear Box x2	BH2013 Front Shock Tower (Aluminum) x1	BH2014 Rear Body Mounts x1
BH2015 Wing Mount Posts x2	BH2016 Center Drive Shaft x1	BH2017 Mount Posts x1	BH2018 Front Bumper x1	BH2019 Brushed Motor x1	BH2020 Brushless Motor x1	BH2021 Pinion Gear 21T x1	BH2022 Motor Plate Holder x1	BH2023 Gear Box Cover x1	BH2024 Steering Rack x1	BH2025 Upper Deck (AL6061) x1	BH2026 Steering Post x2
BH2030 Bearing 5x11x4 x10	BH2031 Bearing 5x13x4 x10	BH2032 Hub Carrier x1	BH2033 CVD Axle(Rear) x2	BH2034 Tie-Rod Set x2	BH2035 Tie-Rod Ends x12	BH2036 Anti Roll Bar(1.8mm) x1	BH2037 Shock Body Sets x2	BH2038 Front Shock Body(AL6061) x2	BH2039 Rear Shock Body(AL6061) x2	BH2040 Front Shock Shaft x2	BH2041 Rear Shock Shaft x2
BH2045 Pins 1.6x9.5 x5	BH2046 Diff Cup Set x2	BH2047 L Wrench 0.05in 0.05 in=1.27mm x1	BH2048 Steering Buffer Set x1	BH2049 Servo Tray Mounts x2	BH2051 Battery Holder(Plastic) x1	BH2052 7.4V Lipo Battery x1	BH2053 Brushed ESC x1	BH2054 Brushless ESC x1	BH2055 Hex Hub x2	BH2078 Buggy Bodysheel(Nacarat) x1	BH2079 Buggy Bodysheel(Blue) x1
BH2060 Shock Set Front(AL6061) x2	BH2061 Shock Set Rear(AL6061) x2	BH2062 Pivot Block(AL6061) x3	BH2063 Rear Shock Tower (Aluminum) x1	BH2064 Tie-Rod Set x1	BH2065 Battery Foam x2	BH2066 E-circlip x2	BH2067 Diff Gear Box x1	BH2068 Bevel Gear Differential x1	BH2069 42T Bevel Gear x1	BH2070 Pinion 14T/19T Bevel Gear x1	BH2071 Diff Gear Shaft x2
BH2072 17T Drive Bevel Pinion Gear x2	BH2086 Shock Set Front(Plastic) x2	BH2087 Shock Set Rear(Plastic) x2	BH2088 Shock Body Sets x2	BH2089 Front Shock Body(Plastic) x2	BH2090 Rear Shock Body(Plastic) x2	WA1070 Front Tires(Green) x1	WA1071 Front Tires (Blue) x1	WA1072 Front Tires(Orange) x1	WA1073 Rear Tires(Green) x1	WA1074 Rear Tires(Blue) x1	WA1075 Rear Tires(Orange) x1
MA2157 Transmitter 2.4G x1	MA2224 Receiver(2.4G) x1	NH3010 Antenna And Mount x1	NH3028 Tie-Rod Ends x8	NH3040 Motor Plate x1	NH3046 Hinge Pin 3x42mm x4	NH3048 Pivot Ball Stud x8	NH3051 Pin 2.0x7.6 x4	NH3054 Ball Stud 4.8x6 x10	NH3056 O-rings x4	NH3059 Bearing 10x15x4 x4	NH3060 Bearing 5x10x4 x8
NH3076 Button Head Screw M3x10 x10	NH3077 Button Head Screw M3x12 x10	NH3078 Set Screw M3x8 x10	NH3079 Set Screw M3x3 x10	NH3081 Set Screw M3x12 x10	NH3084 M4 Nut x10	NH3085 M3 Nut x10	NH3097 Motor Plate Holder(Aluminum) x1	NP0132 Bearing 6x10x3 x1	NP0163 Flat Screw M3x12 x10	NP0004 Set Screw M4x12 x10	NP0053 Button Head Screw M3x16 x10
NP0156 Button Head Screw M3x20 x10	NP0195 Button Head Screw M3x6 x10	NP0250 Button Head Screw M2x8 x10									



Nanda Racing has been making RC products aimed at making our hobby fun and exciting with an affordable price. We are confident that your experience with our products will be positive. Of all the radio controlled models out there, no question about it, RC cars are the hardest to operate. We highly recommend that you read this user manual thoroughly and carefully before assembling and operating. Please follow all precautions and recommendations located within the manual. Be sure to retain the manual for future reference, routine maintenance, and tuning.

Nanda Racing guarantees this product to be free of manufacturing faults and material defects. This product has been checked and fine tuned individually by professional staff and quality control staff. The warranty does not cover any component parts damaged by use and modification. Please visit www.nandaracing.cn for updated information.

This product is not a toy. It is not recommended for children under 14 years old and any minor should be accompanied by an adult when operating. This product is a precision machine that requires proper assembly and setup to avoid accidents. Failure to take caution when operating this product may result in serious injury or property damage. It is the owner's responsibility to operate this product in a safe manner. Manufacturer and its distributors are not responsible in any way for any and all bodily injury(s) and/or property damage that may occur from the use of or caused by in any way or this product.

WARNINGS

- The product is not intended for those under 14 years of age without proper adult supervision. The product is not a toy. It is a precision machine requiring proper assembly and setup to avoid accidents and it is the responsibility of the owner to operate this product in a safe manner as it can cause serious personal injury and damage to property due to carelessness or misuse.
- Do not attempt to disassemble or modify any of the product components without the assistance of an experienced RC user.
- Only use the correct type of battery to operate. Using any wrong type of battery will damage the product and possibly make it dangerous to operate.
- The motor(s) may get hot during use. Always allow 10-15 minutes between each operation for the motor to cool down. This will prolong the life of your product.
- Choose an appropriate operating site consisting of flat, smooth ground, and clear open field. Do not operate near buildings, high voltage cable lines, or trees to ensure safety operation. Operate in safe area only, away from other people. RC models are prone to accidents, failures, and crashes due to a variety of reasons including, lack of maintenance, user error, and radio interference. Users are responsible for their actions and damage or injury occurring during the operation.
- Do not operate in inclement weather, such as rain, wind, snow or darkness.
- The product is composed of sensitive electrical components. It is critical to keep the product away from moisture and other contaminants. Do not allow them to get wet. Electrical damage may occur that could affect safe operation.
- You should complete a successful pre-run check of your radio equipment and model prior to each run.
- After each use, always allow the battery to cool down before recharging. When charging the battery pack, do not overcharge! If batteries get hot during charging, discontinue charging immediately and disconnect the battery from the charger. Never leave battery unattended while charging. If you are unsure of how to charge this battery, please seek the advice of experienced RC users. Never let children charge the battery without adult supervision.
- Always turn on the transmitter before connecting the battery on the model. When turning off the model, always disconnect the battery first, and then turn off the transmitter. If the order is reversed, the model may become uncontrollable and cause serious damage.
- If you are in doubt of your ability to operate model, we strongly recommend that you seek assistance from experienced RC users or join your local modeling club to gain the required knowledge and skill. As the manufacturer and distributor, we assume no liability for the use of this product.
- Before turning on your model and transmitter, please check to make sure no one is operating under the same frequency. Frequency interference can cause your model, or other's models to crash. The guidance provided by experienced RC users will be valuable for the assembly, tuning, trimming, and actual first operating.
- Never allow batteries to run low or you might lose control of the model.
- Plastic is very susceptible to damage or deformation due to extreme heat and cold climate. Do not store the model near any source of heat such as oven or heater. Store the model indoors, in a climate-controlled, room temperature environment.

Charge the Li-Po battery pack

The battery should be fully charged in 2 hours. Disconnect the battery from the charger when the charging process completed. Do not charge the battery unattended at all time.

Lithium Polymer (LiPo) Battery Warnings

- Never charge a lithium polymer battery with a charger designed for NiCd, NiMH, or any other type of battery chemistry. Use ONLY charger designed for LiPo battery.
- Do not leave LiPo battery unattended during charging.
- Do not overcharge the battery.
- Always place the battery on a heat resistant surface alone when charging.
- Always put the LiPo battery inside a charging protection container while charging.
- Do not allow LiPo battery to overheat at any time. Cells which reach greater than 140 Fahrenheit (60°C) will usually become damaged and will catch fire.
- Do not allow LiPo cells or near combustible materials including paper, plastic, carpets, vinyl, leather, and wood, inside an R/C model or full size automobile.
- Do not expose LiPo cell to water or moisture at any time.
- Do not store battery near open flame or heater.
- Do not assemble LiPo cells or pre-assembled packs together with other LiPo cells or packs.
- Always store LiPo battery in a secure location away from children.
- Always remove the LiPo battery if model is involved in any kind of crash. Carefully inspect the battery and connectors for even the smallest damage. CAUTION: cells may be hot!
- Do not allow the electrolyte to get into eyes or on skin. Wash affected areas immediately if they come into contact with electrolyte. Do not alter or modify connectors or wires of a LiPo battery pack.
- Always inspect the condition of the battery before charging and operating.
- Do not short circuit the LiPo battery.
- Do not have contact with a leaky/damaged battery directly.
- Do not charge battery out of recommended temperature rang (0°C-45°C)